

INSTALLATION SLIP ON COUPLINGS

anaco • 1001 El Camino Ave., Corona, CA 92879 • (951) 372-2732

Installation Instructions:

- 1. A hanger shall be required on each side of the coupling on all horizontal runs located within 18 in. of the center of the coupling.
- 2. The clamp assembly shall be torqued to a minimum of 60 inch pounds.
- 3. Couplings shall not be installed in fire rated construction that restricts the use of flammable materials through penetrations or plenums without additional fire-resistive protection.
- 4. Couplings shall be installed in locations where the expected temperatures are between 0-130 degrees F.



Rigid Quick couplings are unshielded transition couplings that are designed to connect various types and sizes of hubless DWV piping material including Cast Iron, Plastic, Steel, Extra Heavy Iron, and Copper in sizes 1¹/₄" through 4". Rigid Quik couplings conform to ASTM C 1461 and are made from Santoprene. Installs similarly to a no-hub coupling and is tightened to 60 inch pounds.